

**45-344 Instructions:**

When cutting the complete cable use 2-step process:

Step 1. Cut/break the jacket and glass fiber with the "Breaker-Notch"  
(patent pending)

Step 2. Trim the Kevlar® aramid strength member with the fine  
serrated edges of the tool.

When only trimming the Kevlar®, the fine serrated edges should be used.  
Suggestion: Periodically clean inside surfaces of blades with a soft cloth.